



Y STORAGE CABINETS





## FLAMMABLE STORAGE CABINETS

Flammable Safety Storage Cabinets provide a safe, close-by, secure and time-saving method for storing all types of dangerous chemicals and help you to maintain good housekeeping practices. All Justrite cabinets are fire tested to comply with the FM rating, something no other cabinet sold in Australia can claim, they also not only comply, but exceed Australian Standard AS 1940. They help companies by providing product near to the workplace thus avoiding the time consuming and often risky practice of collecting from an outside storage facility.

Fully welded construction - 1.2mm steel - Double wall - 40mm thermal barrier

Superior electrostatic high gloss powder coat paint finish / Dual vents with built in flash arresters

Close fitting, sequential self closing and latching doors / 3 point locking mechanisms

Leakproof fully welded 150mm deep containment sump / Shelves with built in troughs to contain spills

Adjustable shelf height increments to maximise space storage

Adjustable levelling feet to prevent doors binding

Fire tested, FM Approved exceeds AS1940 compliance





Safety Can Storage CAT NO: AU25602 3 shelves / Capacity 350 Litre 15 x 20 Litre Drums



Safety Can Storage CAT NO: AU25452 3 shelves / Capacity 250 litre 9 x 20 Litre Drums



Safety Can Storage CAT NO: AU25302 2 shelves / Capacity 160 litre 6 x 20 Litre Drums

**DRUM SAFETY STORAGE** 



AU25304 & AU25308 Slim Line Storage Cabinets Single Door Capacity / 110 & 170 litre

# COMPAC SAFETY CAN STORAGE



Under Bench Storage CAT NO: AU25748 2 shelves / Capacity 100 Litre



Compac Storage CAT NO: AU25714 2 shelves / Capacity 30 Litre



Drum Storage
CAT NO: AU25701
207 Litre Vertical Drum
2 Door with Rollers



Drum Storage CAT NO: AU25662 207 Litre Horizontal Drum 2 Door

Flammable Storage Cabinets			Approval	Weight Kg	H x W x D mm
These cabinets are manufactured for the safe storage of Flammables					
A Safety Shower and Eye/Face wash must be installed where packages are opened					
<b>Drum Cabinets Yellow</b> Powder Paint Finish					
AU25662 207 Litre	Horizontal Drum - 2 Do	oor		168.3	1385 x 765 x 1225
AU25701 207 Litre	Vertical Drum - 2 Door	- with Rollers		192.8	1760 x 870 x 870
AU25602 350 Litre,	3 Shelves, 2 Door,	15 x 20 Litre Drum	FM	177.0	1760 x 870 x 870
AU25452 250 Litre,	3 Shelves, 2 Door,	9 x 20 Litre Drums	FM	142.0	1760 x 1100 x 465
AU25302 160 Litre,	3 Shelves, 2 Door,	6 x 20 Litre Drums	FM	104.8	1230 x 1100 x 465
Tray Top or Under Bench Cabinet Yellow Powder Paint Finish					
AU25748 100 Litre,	2 Shelves, 2 Door		FM	86.1	800 x 920 x 565
Compac Storage Cabinet Yellow Powder Paint Finish					
AU25712 60 Litre, 2	2 Shelves, 1 Door		FM	59.0	1005 x 595 x 465
AU25714T 30 Litre, 2	Shelves, 1 Door		FM	45.0	800 x 595 x 465
Slim Line Flammable Cabinets Yellow Powder Paint Finish					
AU25304 110 Litre,	2 Shelves, 1 Door		FM	95.0	1230 x 670 x 465
AU25308 170 Litre,	3 Shelves, 1 door		FM	135.0	1760 x 670 x 465

### **CORROSIVE SUBSTANCE STORAGE CABINETS**



Corrosive Substance Storage Cabinets have a Polyethylene tray on each shelf to collect any accidental spillages. Designed to withstand fire these cabinets provide a safe environment to store most corrosive chemicals. If you need to store chemicals such as Phenol, Nitric Acid, Sulphuric Acid or other substances with highly corrosive vapours, we suggest you look at the all Polyethylene Cabinets.





Storage Cabinet Cat No: AU25452B

3 shelves / 3 Polyethylene Trays Capacity: 250 Litre / 9 x 20 Litre Drums



Storage Cabinet Cat No: AU25302B

2 shelves / 3 Polyethylene Trays Capacity: 160 Litre / 6 x 20 Litre Drums



Storage Cabinet Cat No: AU25748B

2 shelves / 3 Polyethylene Trays



Storage Cabinet
Cat No: AU25712B
2 shelves / 3 Polyethylene Trays
Capacity: 60 Litre



Polyethylene Storage Cabinet Cat No: AU24160 2 shelves - 30 Litre



Storage Cabinets
Blue Wood Laminated Construction

Corrosives Storage Cabinets		Approval	Weight Kg	H x W x D mm
These Cabinets a	re manufactured to comply with AS 3780 for the			
	orrosive Substances.			
Blue Powder I	Paint Finish			
AU25452B	250 Litre, 3 Shelves, 2 Door, 9 x 20 Litre Drums	FM	143.8	1760 x 1100 x 465
AU25302B	160 Litre, 2 Shelves 2 Door, 6 x 20 Litre Drums	FM	109.8	1230 x 1100 x 465
AU25748B	100 Litre, 2 Shelves, 2 Doors	FM	86.1	800 x 920 x 565
AU25712B	60 Litre, 2 Shelves, I Door	FM	59.0	1005 x 595 x 465
AU25714B	30 Litre, 2 Shelves, I Door	FM	45.0	800 x 595 x 465
Blue Polyethy	lene Construction			
24040	15 Litre, 1 Door		14.0	500 x 365 x 415
24160	30 Litre, 2 Shelves, 2 Door		59.0	890 x 920 x 565
Wood Lamina	nted Construction			
AU24120	6 x 2.5 Litre Bottles, 2 Door		24.0	350 x 560 x 360
AU24140	36 x 2.5 Litre Bottles, 2 door		82.0	758 x 865 x 510
AU24150	49 x 2.5 Litre Bottles 2 Door		125.0	1375 x 1020 x 405

### PESTICIDE STORAGE CABINETS

AU25602P







AU25302P



AU25748P



Pesticide Sto	orage Cabinets	Approval	Weight Kg	H x W x D mm
These cabinets are manufactured for the safe storage of Pesticides.  A Safety Shower and Eye/Wash must be installed where packages are opened.  Storage Cabinets Green Powder Paint Finish.				
AU25602P	350 Litre, 3 Shelves, 2 Door, 15 x 20 Litre Drums	FM	177.8	1760 x 870 x 870
AU25452P	250 Litre, 3 Shelves, 2 Door, 9 x 20 Litre Drums	FM	142.0	1760 x 1100 x 465
AU25302P	160 Litre, 2 Shelves, 2 Door, 6 x 20 Litre Drums	FM	104.8	1230 x 1100 x 465

# TOXIC SUBSTANCE STORAGE CABINETS









AU25714T

AU25748T AU25712T





Toxic Substance Storage Cabinets		Approval	Weight Kg	H x W x D mm
These cabinets are manufactured for the safe storage of Toxics / Poisons				
A Safety Showe	er and Eye/Face wash must be installed where packages are opened			
AU25602T	350 Litre, 3 Shelves, 2 Door, 15 x 20 Litre Drums	FM	177.0	1760 x 870 x 870
AU25452T	250 Litre, 3 Shelves, 2 Door, 9 x 20 Litre Drums	FM	142.0	1760 x 1100 x 465
AU25302T	160 Litre, 3 Shelves, 2 Door, 6 x 20 Litre Drums	FM	104.8	1230 x 1100 x 465
AU25748T	100 Litre, 2 Shelves, 2 Door	FM	86.1	800 x 920 x 565
AU25712T	60 Litre 2 Shelves 1 door	FM	59.0	1005 x 595 x 465
AU25714T	30 Litre, 2 Shelves, 1 Door	FM	45.0	800 x 595 x 465

ALSO AVAILABLE:





ORGANIC PEROXIDE CABINETS & OXIDIZING AGENT CABINETS

## Justrite Dangerous Goods Storage Cabinets — Features & Benefits



self-close models).



Patented concealed selfclose mechanism provides obstruction free access to top shelf space. Self-indexing doors guarantee they will close in sequence and assure a tight closure from top to bottom (on self-close models).

NO IGNITION SOURCES WITHIN 3m

LAMMABLE



Rounded safety corners on doors reduce accidental nicks or cuts and potential hand injury



Haz-Alert™ Reflective labeling provides high visibility in the dark under fire conditions or power outage when illuminated by a flashlight beam. Patent Pending.



Stainless steel, three-point bullet self-latching system provides easy, fail-safe, positive door closure with increased heat resistance.



Exclusive U-Loc™ Padlockable Handle. Optional padlock allows for extra security and keycoding multiples for convenient access. Flush paddle handle with slip resistant grip offers easy fingertip opeation and educes dangerous catches from passing taffic.

Double key set included for keyed lock. Patent Pending



Minimal air-gaps provide better protection.

melts at 74°C for automatic closure (on

Double wall thermal barrier. 1.2mm sheet steel thickness with 40mm wall spacing.

Easy close, selflatching doors.

Fully-welded (not riveted) construction holds squareness for longer life, offering greater protection in a fire since air gaps are reduced.

Continuous piano hinge provides smooth closure.

Built-in grounding connector (on outside side panel) for easy grounding.

Dual vents with builtin flame arresters strategically placed at bottom and opposite top are welded, not screwed in place.

Durable and chemical resistant, hybrid leadfree powder coat paint finish, insideand-out, retains high gloss look and minimizes the effects of corrosion and humidity.



Adjustable leveling feet for stability on uneven surfaces.



Welded shelf hangers interlock with shelf to offer maximun'ino slip" stability... and no flimsy brackets to lose.



FM

Exclusive SpillSlope™ safety shelves diects spills to back and bottom of leak proof sumpleavy-gauge galvanized steel shelves are bi-directional and easily adjust on 76mm centers for versatile stope. Each cabinet is provide standard with 150 mm deep sump to contain spills or leaks within the cabinet.

#### DOCUMENT STORAGE BOXES



Conveniently stores and protects important papers at worksite. Ideal for MSDS sheets and operating guides for all kinds of equipment.

#### MANIFEST BOXES





Keyed 003 Emergency services & Fire Brigade lock. Weatherproof.

# **JUSTRITE SAFETY CANS**

### FLAMMABLE SAFETY STORAGE CANS & PRODUCTION SAFETY EQUIPMENT

Fire protective storage of flammables. Heavy-duty with double-seamed construction. All models have built in flash arresters to eliminate the risk from flashback causing explosion.









**SAFETY STORAGE CANS** 

**SAFETY FUNNELS** 

**POLYETHYLENE CANS** 



**OILY WASTE CANS** 



SAFETY DISPENSING CANS



SHELF DISPENSING



**PLUNGER CANS** 



**BENCH CANS** 



**DISPOSAL CANS** 



**FITTINGS** 



RETRACTABLE STATIC GROUNDING REELS

